

VALE TABLE LAMP

SKU# 251081

Rated Voltage 220-240V~ 50Hz

To ensure proper operation and safety, please read and follow all instructions carefully before assembling, installing, or using this product. Retain these instructions for future reference.

Warranty

- This portable luminaire is covered by a 12-month warranty from the date of purchase.
- For after-sales service or warranty claims, please contact your retailer or an authorized distributor.
- The warranty period begins on the date of purchase — please retain your proof of purchase as it will be required for any warranty claim.
- The warranty will be void if the product has been damaged due to improper use, misuse, or modification.
- Failure to follow the instructions outlined in this manual may result in damage or injury and will void the warranty.
- This warranty is provided in addition to your rights under the Australian Consumer Law.

Installation Requirements


- Select an appropriate location for the portable luminaire:
 - Place it on a flat, stable surface.
 - For indoor use only.
 - Keep flammable materials away from and above the luminaire.
 - Avoid installing the luminaire directly in the path of air vents or air conditioning systems.
 - If placed in a moisture-prone area, ensure the space is well-ventilated and fitted with a suitable exhaust fan if required.
 - Note: Damage or corrosion caused by moisture is not considered a product fault and is not covered under warranty.
- Do not exceed the maximum wattage rating.
- Handle all electrical wires with care during unpacking to prevent damage to internal connections.
- Before assembly, lay out all components on a smooth surface and confirm that no parts are missing.
- Inspect the luminaire for any signs of damage during transport. Do not assemble or operate the product if it appears damaged.
- Do not plug the power cord into the mains outlet before or during assembly. Only connect it once the luminaire is fully assembled, the globe is installed, and the product is ready for first-time use.

Installation Directions

Please refer to the illustration for part identification.

1. Carefully remove all packaging materials from the portable luminaire. Ensure that no accessories are accidentally discarded, as some may be hidden within the packaging.
2. Place the luminaire on a smooth, non-scratch surface to assist with assembly.
3. Make sure to remove all protective packaging from the lamp shade (C) before use.
4. Unscrew and remove the lamp holder skirt (B) from the lamp holder (D).
5. Position the lamp shade (C) onto the lamp holder (D), then secure it by reattaching the lamp holder skirt (B).

6. Install a suitable globe (A – not included) into the lamp holder (D). **Do not exceed the maximum wattage rating.**
7. Choose an appropriate location for the luminaire, following the installation requirements outlined above.
8. Insert the plug (E) fully into a mains power outlet.
9. Switch on the power at the mains outlet.
10. Use the cord line switch (F) to switch the portable lamp ON/OFF.



Safety Tips

- Always switch off the power and allow the portable luminaire to cool completely before carrying out any maintenance, cleaning, globe replacement, or adjustment.
- If the external flexible cable or cord of this luminaire becomes damaged, it must only be replaced by the manufacturer, their service agent, or another suitably qualified person to prevent potential hazards.
- Ensure young children are supervised and do not play with the luminaire.
- Handle the luminaire and its shade carefully to prevent damage or breakage.
- Place the luminaire in a suitable location, away from liquids, heat sources, and other hazards.
- To clean, wipe gently with a soft, damp cloth. Do **not** immerse the luminaire in water or any other liquids.
- Keep the luminaire away from corrosive chemicals, solvents, and abrasive cleaning agents.

Specifications	
SKU #	251081
Colour	Green/White
Rated Voltage	220–240V~ 50Hz
Rated Wattage	45W Max.
Lamp Holder	SES / E14
Weight	1.80kg
Dimensions	H:490mm Dia:300mm